

<https://servicepro.icb.com/products/793991813529601602/parts?filters=%7B%22activePage%22%3A%225c0f2985-1819-40c3-bcc5-e84f4e449e26%22%2C%22s...>

18	:02/100396	Plug core D=32mm < Supersession	3
19	:02/101784	Cover	1
20	:02/101785	Gasket < Supersession	1
21	:02/291016	Screw	3
21	826/00869	Screw Flange Head	1
22	02/200511	Gasket cylinder head < Supersession	1
23	02/100122	Bolt cylinder head < Supersession	2
24	02/100120	Bolt cylinder head check engine for quatities either 10 or 12 bolts < Supersession	12
25	02/100121	Bolt cylinder head < Supersession	18
26	02/100148	Plug < Supersession	1
27	823/00264	Washer Aluminium (I/D=16mm) < Supersession	1
28	02/100095	Plug taper < Supersession Locates in cylinder head left hand side,front	1
29	02/001000	Plug	3