


D1-3-1 CONTROL, KNOB GEAR CHANGE



256650

4	701/42600	Switch push button black with microswitch <M881461 Supersession >	1
4	701/43500	Switch micro >M881462 Supersession >	1
5	817/04362	Decal gear lever 4-speed	1
5	817/04522	Decal gear lever 3-speed	1
6	160/01116	Knob 'Screw on' < Supersession	1
7	:826/01446	Insert threaded Supersession >	1