




|     |            |                                                                                                                   |   |
|-----|------------|-------------------------------------------------------------------------------------------------------------------|---|
| A   | 283/19006  | AIR CLEANER G.A. AIR CLEANER G.A.                                                                                 | 1 |
| 1   | 580/12154  | Kit-air filter                                                                                                    | 1 |
| 2   | :32/920401 | Element air filter main<br>< Supersession                                                                         | 1 |
| 3   | :32/920402 | Element air filter safety                                                                                         | 1 |
| 4   | :32/925200 | Cover end                                                                                                         | 1 |
| 5   | :32/925211 | Clip overcentre                                                                                                   | 3 |
| 6   | :32/916603 | Valve Dust<br>< Supersession                                                                                      | 1 |
| 7   | :32/925548 | Band mounting                                                                                                     | 2 |
| 8   | 1315/0309D | Setscrew M8 x 35 mm<br>< Supersession                                                                             | 4 |
| 9   | 1412/0003D | Washer (3/8" Large)                                                                                               | 8 |
| 10  | 1370/0203D | Nut Lock M8<br>< Supersession                                                                                     | 4 |
| 11  | 834/10283  | Hose air induction                                                                                                | 1 |
| 12  | 162/02674  | Sensor Adapter Vacuum                                                                                             | 1 |
| 13A | :580/12126 | Disc felt                                                                                                         | 1 |
| 13  | JNH0070    | Adaptor Vacuum Sensor                                                                                             | 1 |
| 14  | 834/10281  | Hose air induction                                                                                                | 1 |
| 15  | 830/10627  | Tube air induction                                                                                                | 1 |
| 16  | 32/920404  | Cap rain                                                                                                          | 1 |
| 17  | 2201/0017  | Clip Worm Drive 110-140mm<br>< Supersession                                                                       | 1 |
| 18  | 2201/0016  | Clip Wormdrive 90/110mm<br>< Supersession                                                                         | 3 |
| 19  | 331/37802  | Bracket adapter air filter<br>to JUL09<br>Air cleaner mounted directly to hydraulic tank<br>> No Longer Available | 1 |

|    |                                                                                              |                                                               |   |
|----|----------------------------------------------------------------------------------------------|---------------------------------------------------------------|---|
| 19 |  Not for sale | Plate spacer<br><i>from M830534</i><br>Fitted to two machines | 1 |
| 20 | 1315/0307D                                                                                   | Setscrew M8 x 25mm G8.8<br><i>to JUL09</i><br>Supersession >  | 4 |
| 21 | 1420/0007D                                                                                   | Washer M8<br><i>to JUL09</i><br>< Supersession                | 8 |
| 22 | 1370/0203D                                                                                   | Nut Lock M8<br><i>to JUL09</i><br>< Supersession              | 4 |